




KWIK HUS-EZ	$h_1^*$	$t_{fix}$
$\frac{5}{8} \times 3\frac{1}{2}$	$3\frac{3}{8} - t_{fix}$	0... $\frac{1}{4}$
$\frac{5}{8} \times 4$	$4\frac{3}{8} - t_{fix}$	0... $\frac{3}{4}$
$\frac{5}{8} \times 5\frac{1}{2}$	$5\frac{7}{8} - t_{fix}$	0... $\frac{1}{2}$
$\frac{5}{8} \times 6\frac{1}{2}$	$6\frac{7}{8} - t_{fix}$	0... $1\frac{1}{2}$
$\frac{5}{8} \times 8$	$8\frac{3}{8} - t_{fix}$	0...3



<b>2.1</b>		
SIW 22T/18T-A	✓	✓
SIW 9-A22	✓	⊘
	85 ft-lb	38 ft-lb



\*For non-hole cleaning installation (steps 1a or 1b), make sure to drill deep enough to achieve  $h_1$ , taking into account the depth of debris remaining in the hole.